








Tefal







INOX





1. FIRST USE



2. TOASTING





3. HIGH-LIFT








4. STOP/EJECT






stop/eject







5. REHEAT



6. DEFROST



7. CLEANING



8. DO NOT

