





Warning

The energy consumption of this machine in off mode is less than 0.5 Watt.
This means that this machine complies with European Directive 2009/125/EC,
which sets the ecological design requirements for energy-using products.

If the coffee machine has already been used and therefore has been flushed with water, it may only be used and stored in a frost-free place to prevent it from becoming damaged.

Sauberes kaltes Wasser
Verwenden Sie täglich sauberes kaltes Wasser. War die Maschine über 1 Tag nicht

sauberm kaltem Wasser, stellen Sie eine Schüssel oder zwei Tassen unter den Auslauf, und drücken Sie mehrmals die 2-Tassen- Taste, damit heißes Wasser durchläuft, bis der Wassertank leer ist.

- 2 Diese werden dort fachgerecht gesammelt oder zur Wiederverwendung vorbereitet. Altgeräte können Schadstoffe enthalten, die der Umwelt und der menschlichen Gesundheit schaden können. Enthaltene Rohstoffe können

